

CASTER MOUNT CAP REPLACEMENT

Tools Needed:

- A small flathead screwdriver



Step 1: Using a small flathead screwdriver pry at the cap above caster wheels.



Illustration: Caster mount cap removed.



Step 2: Insert the replacement caster mount cap and secure it tightly.



Step 3: Push in tightly making sure it's secured.



The End: Congratulations, you have successfully replaced the caster mount cap!