

Customers may need to do the re-syncing procedure because they ordered a new handset or received a replacement handset. In some cases, your handset can lose sync with the CaddyTrek unit. Below are simple instructions on the re-syncing procedure.

1. Turn OFF the CaddyTrek unit and handset. [figure a]
2. Turn ON the CaddyTrek unit.
3. Then with-in five seconds, turn ON the handset.
4. Immediately after turning the handset ON, press and hold the STOP button while repeatedly pressing the UP button. [figure b]
5. Continue holding the STOP button while repeatedly pressing the UP button on the handset.  
NOTE: Re-syncing can take 5-10 seconds. It may be necessary to restart the process if too much time passes between turning on the unit and the handset.
6. Successfully re-syncing your handset with your unit will be signified by 2 short beeps coming from the handset. Your handset will then revert to SB, or Stand-By Mode.
7. Pairing successful! You may now continue using your CaddyTrek.



### ***CaddyTrek Handset Checks***

- Check for the overall tactile feel of handset buttons. Are they stuck, loose, or normal?
- Remove the handset battery, and re-insert it. Upon re-inserting the handset battery, you should hear a long beep sound signifying that both the handset and handset battery are functioning.
- When charging your handset battery, the LED indicator should be red for charging and green for when charging is complete.
- The LED indicator switches to green when you remove the handset battery while the handset is still plugged in.
- When powering on your handset you should hear a long beep sound. Shortly afterwards, you should hear 2 short beeps that signifies handset pairing.
- To check handset battery levels, hold the orange STOP button.
- Check modes: SB (Stand-By), RC (Remote Control), FL (Follow)

